





Globe II Business Centre, 128 Maltravers Road, Sheffield, S2 5AZ Tel. No. (0114) 272 4342
Fax. No. (0114) 279 7700
E-Mail: sales@troikaam.co.uk
Websites: www.troikaam.co.uk
www.plasterware.net

FIXING INSTRUCTIONS FIRE SURROUNDS

- 1. Bed marble hearth on sand / cement mortar.
- 2. Fix marble back to wall using "Troika Fix" or a good tile adhesive
- 3. Position surround around marble and mark position of wire supports on wall and drill hole to receive fixing.
- Remove surround.
- 5. Hack away a small area of plaster around each wire support.
- 6. Apply "Troika Fix" to the back of the surround where it makes contact with the wall.
- 7. Re-position surround and plug and screw to wall through supports.
- 8. Clean away excess adhesive and fill joints with fine casting plaster.
- 9. Patch wall and plaster over wire supports.